


## Multimedia Home Entertainment Video Projector



Quick User Guide-Z400

To ensure safe and proper use, please read this instruction before operating the product.

# English

## Warranty

Your projector comes with a free replacement or a full refund within 1 year that lets your product with confidence.



#### **Contact Us**

Whether you need further assistance, are looking for answers, or just want to share your reviews with us, you will find many ways to contact us right here.

- · E-mail:service@iragu.net
- Call:1-262-299-0397 (available for customers in the United States currently)



## **Important Safety Instructions**



 Don't use chemical detergents to clean



 Don't look directly into the light



 Don't disassemble the projector



 Unplug the projector after shutdown



 Use a soft and dry cloth for cleaning



 Don't use the projector near water or moisture



 Don't block any ventilation openings




 Place the projector on a flat surface



 Use in a wellventilated area





#### **Box Contents**



Note: Adjust the focus ring and the keystone ring before using the projector. Turn off this product when not in use to prolong the life of the projector.


#### **Product Parts**






- 1. VGA port
- 2. SD card slot
- 3. AV input port
- 4. Audio jack
- 5. HDMI port
- 6. USB port
- 7. 5V output port






#### Remote Control




- 1. Power Button (turns the projector on or off)
- 2. Mute Button (turns off sound)
- 3. Fast Backward Button
- 4. Play/Pause Button (plays/stops playing audio or video)
- 5. Fast Forward Button
- 6. Ok Button (selects options)
- 7. Up (selects upward movement)
- 8. Down (selects downward movement)
- 9. Left (selects leftward movement)
- 10. Right (selects rightward movement)
- 11. Esc Button (cancels/exits functions)
- 12. Menu Button (accesses projector menu system)
- 13. Source Button (selects of the input source)
- 14. Volume Down Button (adjusts speaker volume)
- 15. Volume Up Button (adjusts speaker volume)


## **Projector Operations**

1. Connect the power cord to the projector's power inlet, press the Power Button to turn on the projector.






2. Rotate the Focus Ring and the Keystone Correction simultaneously until to get the clear image.






Press the Menu Button. Press Left/Right to select Option. Choose OSD Language under Option.






4. Press Ok to access the submenu of OSD Language and press Up/Down/Left/Right to select the language.







5. To connect a device, press the Input Button or the Source Button.



6. Select the correct input source and prepare the cable for device connections if necessary.






## Flexible Connectivity


Connect the projector to your device with the compatible cable and port.

Note: Do not hot plug the device, power off the device before making any connections.







Connect to a HDMI device




Connect to a USB storage device up to 64G




Connect to a VGA device



Connect to an audio device



Connect to an AV equipment



Charge a mobile device

If you follow the above connecting steps, however, there is no display or it does not work, please refer to the detailed instruction manual or contact us to solve the problems.

## **Product Specifications**


















Imaging Technology	TFT LCD
Native Resolution	800x480 Pixels
Maximum Supported Resolution	1920x1080 Pixels
Light	LED
Lens	Multichip Coated Lens(F=125)
Keystone	± 15 ° Correction
Screen Size	50-130 inches
Projection Distance	1.5-4.0m
Recommended Projection Distance	1.51-2.2m with screen size of 50-72 inches
Projection Ratio	1.4:1
Aspect Ratio	16:10
Color	16.7k
Consumption	50W(Max)
Power Supply	100-240V(50/60 Hz)-20V/2A
Supported Audio Formats	MP3/WMA/OGG/AAC/FLAC/APE/WAV
Supported Image Formats	PEG/BMP/PNG
Supported File Format	TXT

## **Projection Distance and Screen Size**





## **Helpful Tips**

- · Please operate the projector in a dark room.
- The cooling system makes slight noise to avoid overheating.
- Connecting to an external audio device is recommended.
- · Business data presentation is not recommended.
- Maximum supported resolution of the projector is 1920x1080 Pixels.
- Native resolution of the projector is 800x480 Pixels.
- The projector does not support Dolby Vision.
- Mirror a smartphone to the projector with a HDMI/WiFi dongle.

